

# WIZEDRIVE-101M

## Mini



### Specification

<b>GSM Module</b>	Four-Band GSM850, 900, 1800, 1900(MHz)
<b>GPRS connectivity</b>	GPRS multi-slot class 10, GPRS mobile station class B
<b>GPS Module</b>	Ubox 7020
<b>Position accuracy</b>	10 meters, 2D RMS
<b>Tracking sensitivity</b>	- 159dBm
<b>Acquisition sensitivity</b>	- 144dBm
<b>Acquisition</b>	Hot start 1s, warm start 30s,cold start 32s
<b>Indicator LED</b>	3colors indicator: Power, GPS, GSM
<b>Product feature</b>	Small, easy to install. Built-in switching power, wide voltage input range. Can be powered by cigarette lighter or vehicle battery power.

### Hardware Features

<b>Positioning</b>	Location tracking via SMS, GPRS (TCP, UDP): SMS location tracking. Signal real time location tracking. GPRS location tracking via time interval. GPS position from every 10 sec.
<b>Alarm</b>	Main power cut off alarm. Shock alarm. Over speed alarm.



**Installed on site by professionals with over  
30 years experience in vehicle tracking technology**



## ***Special features (work with our tracking software)***

<b>Monitor</b>	Get real time position and alarms notice. Get last position. Position data includes: terminal ID, time, address, position validity, alarm (over-speed, SOS), vehicle status (engine, door, shock), speed, mileage, direction, GSM signal, GPS signal, Longitude, Latitude.
<b>Mileage</b>	Mileage statistics, can synchronize initial mileage. Working time and non-working time driving mileage statistics.
<b>Geo-fence</b>	Area-in alarm, area-out alarm, and set geo-fence area as station. Set geo-fence area as station and manage the in, out vehicle. Fence type includes: round, rectangle, polygon, broken line. Fence alarm real time notes, and can send alarm info to user specified mobile phone and email.
<b>Reports</b>	Vehicle exceeds any speed enquiry. Vehicle various speed statistics. Vehicle parking time and address report. Vehicle daily running info report. Vehicle the vehicles that go through specified location. Driver over time fatigue driving report. Stat. engine on time, door open, close time, vehicle shock info. Mileage, speed curve chart display.

### **CAPE TOWN**

Riaan Wium  
4 Woltemade Street  
Gansbaai, WC  
Cell: 082 941 5901  
Email: info@wizedrive.com  
Skype: riaanwium

### **PORT ELIZABETH**

Pieter Kitshoff  
18 Deliville Street  
Lorraine, Port Elizabeth, EC  
Cell: 082 117 0112  
Email: pieter@wizedrive.com  
Skype: pieter.kitshoff

### **GAUTENG**

Ernie  
6 Wylie Street  
Boksburg, Gauteng  
Cell: 083 227 2581  
Email: ernie@wizedrive.com

### **NAMIBIA**

Werner Verwey  
Cell: +264 81 251 2450  
Email: verweyw@gmail.com